

**1 Before driving****1-1. Hybrid system**

Hybrid system..... 24

**1-2. Key information**

Keys ..... 36

**1-3. Opening, closing and locking  
the doors and trunk**Smart access system with  
push-button start ..... 41

Wireless remote control..... 53

Doors..... 55

Trunk..... 60

**1-4. Adjustable components  
(seats, mirrors, steering wheel)**

Front seats..... 65

Driving position memory  
system ..... 67

Head restraints..... 72

Seat belts ..... 75

Steering wheel..... 82

Inside rear view mirror ..... 83

Outside rear view mirrors..... 85

**1-5. Opening and closing  
the windows and moon roof**

Power windows..... 87

Moon roof ..... 90

**1-6. Refueling**

Opening the fuel tank cap..... 94

**1-7. Theft deterrent system**

Immobilizer system ..... 99

Alarm..... 101

**1-8. Safety information**

Correct driving posture ..... 104

SRS airbags ..... 106

Front passenger occupant  
classification system..... 118

Child restraint systems ..... 123

Installing child restraints ..... 127

## 2 When driving

### 2-1. Driving procedures

Driving the vehicle.....	138
Power (ignition) switch.....	148
Transmission .....	152
Turn signal lever .....	156
Parking brake .....	157
Horn.....	158

### 2-2. Instrument cluster

Gauges and meters .....	159
Indicators and warning lights.....	163
Multi-information display.....	166

### 2-3. Operating the lights and windshield wipers

Headlight switch.....	169
Fog light switch .....	172
Windshield wipers and washer.....	173
Headlight cleaner switch .....	178

### 2-4. Using other driving systems

Cruise control .....	179
Dynamic radar cruise control.....	183
Intuitive parking assist .....	195
Rear view monitor system .....	208
AVS (Adaptive Variable Suspension System).....	212
Driving assist systems.....	213
PCS (Pre-Collision System) .....	220

### 2-5. Driving information

Cargo and luggage.....	227
Vehicle load limits.....	231
Winter driving tips .....	232
Trailer towing.....	237
Dinghy towing .....	238

## 3 Interior features

### 3-1. Using the touch screen

Touch screen .....	242
Setting the touch screen .....	248

**3-2. Using the air conditioning system and defogger**

Automatic air conditioning system .....	259
Rear window and outside rear view mirror defoggers .....	268
Windshield wiper de-icer .....	269

**3-3. Using the audio system**

Audio system type .....	270
Using the radio.....	273
Using the CD/DVD player.....	282
Playing an audio CD.....	285
Playing MP3 and WMA discs.....	289
Playing DVD video/audio (with DVD player).....	293
Playing a video CD (with DVD player).....	307
CD/DVD player and DVD video disc information.....	310
Listening to Bluetooth® audio .....	321
Listening to a USB memory/iPod .....	329
Optimal use of the audio/video system.....	339
Using the AUX port.....	341
Using the steering switches .....	342

**3-4. Using the hands-free system (for cellular phone)**

Hands-free system (for cellular phone).....	345
Using a Bluetooth® phone .....	351
Setting the hands-free system (for cellular phone).....	366

**3-5. Using the interior lights**

Interior lights list.....	395
---------------------------	-----

**3-6. Using the storage features**

List of storage features.....	398
-------------------------------	-----

**3-7. Other interior features**

Sun visors.....	406
Vanity mirrors.....	407
Clock.....	408
Outside temperature display .....	409
Ashtrays .....	410
Cigarette lighter .....	411
Power outlet.....	412
Seat heaters/ventilators.....	413
Armrest .....	415
Rear sunshade.....	416
Floor mats.....	419
Trunk features.....	421
Garage door opener .....	423
Compass.....	430
Safety Connect .....	434

## 4 Maintenance and care

### 4-1. Maintenance and care

Cleaning and protecting the vehicle exterior .....	442
Cleaning and protecting the vehicle interior .....	445

### 4-2. Maintenance

Maintenance requirements .....	448
General maintenance .....	450
Emission inspection and maintenance (I/M) programs .....	453

### 4-3. Do-it-yourself maintenance

Do-it-yourself service precautions .....	454
Hood .....	457
Positioning a floor jack .....	458
Engine compartment .....	460
Tires .....	475
Tire inflation pressure .....	485
Wheels .....	489
Air conditioning filter .....	491
Electronic key battery .....	494
Checking and replacing fuses .....	496
Headlight aim .....	511
Light bulbs .....	514

## 5 When trouble arises

### 5-1. Essential information

Emergency flashers .....	522
If your vehicle needs to be towed .....	523
If you think something is wrong .....	531
Event data recorder .....	532

**5-2. Steps to take in an emergency**

If a warning light turns on or a warning buzzer sounds.....	534
If a warning message is displayed.....	544
If you have a flat tire (Vehicles with standard tires).....	561
If you have a flat tire (Vehicles with run-flat tires).....	571
If the hybrid system will not start.....	572
If the shift lever cannot be shifted from "P".....	573
If you lose your keys.....	574
If the electronic key does not operate properly.....	575
If the 12 volt battery is discharged.....	578
If your vehicle overheats.....	581
If the vehicle becomes stuck.....	584
If your vehicle has to be stopped in an emergency.....	586

**6 Vehicle specifications****6-1. Specifications**

Maintenance data (fuel, oil level, etc.).....	588
Fuel information.....	598
Tire information.....	601

**6-2. Customization**

Customizable features.....	615
----------------------------	-----

**6-3. Initialization**

Items to initialize.....	621
--------------------------	-----

**7 For owners**

Reporting safety defects for U.S. owners.....	624
Seat belt instructions for Canadian owners (in French).....	625
SRS airbag instructions for Canadian owners (in French).....	627

## Index

Abbreviation list ..... 636

Alphabetical index ..... 638

What to do if..... 648

1

2

3

4

5

6

7